




1. INTRODUCTION.


Designing fixed frame insect screens in the MB-CAD program is based on the scheme of adding window fittings to the existing window structure. The solution is available as an addition to the fittings. After accepting the detailed settings, the profiles for the net frame and the mesh will be automatically recalculated to the size of the given sash. The user can configure:

- type of mesh,
- type of frame profiles,
- optional use of horizontal transom,
- type of corner connections (crimped/screwed),
- optional use of mounting bracket.

2. ADDING THE INSECT SCREEN IN THE CONSTRUCTION.


1) Select the window to be supplemented with an insect screen.






Additions:

Select an option MRSZ insect screen.



MRSZ

3) Start configuration of the insect screen with Additional settings.



3. An exemplary view of the MRSZ insect screen with default settings, added to the tilt&turn window in the MB-86N system.

